



DRAW. POS.	PART NAME OF A4G404 SERIE	PART NUMBER
1	SAE FRONT COVER	A4G404.01
2	AIR OUTLET	A4G404.02
3	DRIVE PLATE	A4G404.03
4	FAN	A4G404.04
5	ROTOR WITH WINDING	A4G404.05
6	RECTIFIER MODULE	A4G404.06
7	EXCITER ROTOR	A4G404.07
8	STATOR WITH WINDING	A4G404.08
9	HOUSING	A4G404.09
10	TERMINAL BOX	A4G404.10
11	AVR	A4G404.11
12	AVR LID	A4G404.12
13	COPPER PLATE	A4G404.13
14	TERMINALPOST	A4G404.14
15	NON DRIVE-END BRACKET	A4G404.15
16	BEARING COVER	A4G404.16
17	NON DRIVE-END COVER	A4G404.17
18	AIR INTAKE COVER	A4G404.18
19	EXCITER STATOR	A4G404.19
20	AIR INTAKE	A4G404.20
21	BEARING	A4G404.21
22	BEARING HOUSING	A4G404.22
23	SHAFT	A4G404.23

A4G404 SERIES

